



TECHNIAL SUPPORT

DELETING PAIRED DEVICE TECH TIP

CDE RADIOS



DELETING PHONES FROM THE PAIRED DEVICE LIST



- Step 1: Press and hold audio set up button for 3 seconds

Step 2: Rotate volume knob to select bluetooth and press enter

Step 3: Rotate volume knob to select paired dev. and press enter

Step 4: The paired device will be highlighted press enter to select

Step 5: Rotate volume knob to select clear and press enter

Step 6: Rotate volume knob to select yes and press enter

The selected device will be cleared

Repeat steps 1 through 6 to clear other paired devices

Document Illustrated and Approved By: Technical Support Alpine Electronics of America, Inc. 1-800-TECH-101	Additional Specifications: N/A	Circuit Profile N/A
Revision: 012915		
ICs and other components may vary with certain applications. Due to ongoing changes manufactured vehicles, this documents will be subjected to change without notice.		