Software Update Procedure INE-W977HD

7-Inch Mechless Navigation Receiver

Introduction


- This installation manual is designed to take you through the step-by-step installation of the firmware version 5.1 update and the navigation update into an INE-W977HD. Please familiarize yourself with the owners manual (found at www.alpine-usa.com/support) and if you still have additional questions please call 1-800-TECH-101. This update includes the following:
- MyQ Geofencing feature: This will show a popup notification when the user is arriving home to access the garage door feature.
- Favorites Update: The ability to store apps from Alpine Connect including iHeart Radio, Glympse, Yelp, MyQ, and Alpine Go! in the Favorites screen (which is accessed by pressing the start key).
- Audio Update: Enhances the speed and makes the head unit smoother and more fluid to operate
- Fixes issue with Samsung phones when getting an incoming call and the ringing continues after answering.

Caution!

- Do **NOT** turn off vehicle's ignition or head unit's power switch while updating. Some modern vehicles may shut down the ignition (ACC) if the engine is not running for some time. If you are not sure if this applies to your car, leave the engine running while the update is in progress.
- Do **NOT** remove the USB flash memory while updating.
- Do NOT press any buttons while updating.
- Do **NOT** update while driving.
- Failing to follow any of these cautions could cause damage to the head unit.

Step 1: Format The Flash Drive

- 1-1 Only flash drives formatted to FAT32 can be read by the head unit. This means that your flash drive can not be formatted to anything else including NTFS, exFAT, etc.
- 1-2 In Windows the drive can be formatted by right clicking on the drive in file explorer and selecting format as shown in the pictures below.



Step 2: Copy The Audio Update Files To The Flash Drive

2-1 Extract the downloaded files using a program like WinZip to your computer. If you don't have a program that handles zip files on your computer you will need to install one.

Open INE-W977HD_NL Common Open with WinRAR 00006Arar Extract files_	I Image: v New folder File Home Share View Image: main state View New folder		- D
Extract Here Extract to INE-W977HD_NL00006A\ Scan INE-W977HD_NL00006Arar Share Open with Give access to Restore previous versions Send to Cut Copy Create shortcut Delete Rename Properties	A CheChive A CheChive A CheChive B Convertes Petures Petur	Extracting from INE Archeve C/Warrier/Beach_WERE-W97760_KL00006A.arr extraining 24% Extraining 24% Extraining 26% Extraction 00.00.00 Processed 6% Extraction Process Extraction Proc	Constraints of the second

2-2 The extracted folder is named NL00006A. Copy the unzipped folder to your flash drive by copy and pasting or dragging and dropping the file. The pictures below show the folder NL00006A on the flash drive and the folders in it. Note: You can **NOT** change the file names or folder names. The head unit will not recognize the files if you do.


★ Quick access Name ▲ Desktop ★ ▶ Downloads ★ № Documents ★		Date modified 3/7/2018 11:05 AN	Type Size File folder			
💺 Pictures 🖈	■iii 10% complete Copying 17 items from Audio to USB Drive (F:) 10% complete	- · ×	e View .100 Limo > INE-W977HD > NL00006A			
			Name	Date modified	Туре	Size
	-		buprog.bin	5/15/2019 4:47 AM	BIN File	1,536 KB
le OneDrive	Ore details		🎸 imxapsw.img	5/15/2019 4:47 AM	IMG File	56,729 KB
🎐 This PC			🎸 imxapswupd.img	5/15/2019 4:47 AM	IMG File	81 KB
👆 3D Objects			🈏 imxbl.img	5/15/2019 4:47 AM	IMG File	229 KB
hesktop			🎸 imxdtb.img	5/15/2019 4:47 AM	IMG File	52 KB
Documents			🎸 imxdtbupd.img	5/15/2019 4:47 AM	IMG File	52 KB
🔈 Downloads			🎸 imxgpsw.img	5/15/2019 4:47 AM	IMG File	36,805 KB
> 🐌 Music			🎸 imxgpswupd.img	5/15/2019 4:47 AM	IMG File	18,546 KB
🔚 Pictures			ઇ imxkern.img	5/15/2019 4:47 AM	IMG File	2,972 KB
Videos			🎸 imxkernupd.img	5/15/2019 4:47 AM	IMG File	2,972 KB
💺 Local Disk (C:)			📄 order.apn	5/15/2019 4:47 AM	APN File	1 KB
			📄 orderupd.apn	5/15/2019 4:47 AM	APN File	1 KB

Notes:

- *Do **NOT** store any other files on the flash drive. If there is anything on the drive besides the update files it will not read correctly.
- *Certain manufacturer's USB memory may not work. If so, try a different manufacturer's USB memory.

Step 3: Copy The Update Files To The Head Unit

3-1 Plug the flash drive into the USB connector of the head unit. The USB extension is typically ran from the back of the head unit to either the glove box or center console areas of the vehicle depending on the original installation.



- **3-2** Turn on the vehicle's ignition to power on the head unit. Do **NOT** turn off the igntion or the power of the head unit while the system is updating!
- **3-3** The head unit will automatically read the files on the flash drive and an update message will appear on the screen. Press the "OK" button when it asks. The update will begin in about 20 seconds and will take about 3-4 minutes to complete.



- **3-4** When the software update is finished the head unit will automatically restart. Run the software update for a 2nd time.
- 3-5 Turn off the vehicle's ignition, remove the USB memory, and turn the ignition back on to finalize the software update. Please check the version number of the Software in the Setup menu of the INE-W977HD (MENU/SETUP/GENERAL/ABOUT). As always to get into the settings the parking brake sequence will need to be done. The parking brake needs to be engaged, then released, then engaged again. If the software version number is displayed as "5.1000.5.1000", the update procedure was successful



INE-W977HD

Troubleshooting Guide

	Symptom	Possible Cause	Remedy		
1		The downloaded software was not unzipped.	Refer to Step 2. The .zip file will need to be unzipped first using your program of choice (for example, WinZip, WinRAR, Izarc, etc).		
		There are other files on the flash drive.	The flash drive should be freshly formatted (refer to Step 1) and the only files on it should be the downloaded files as shown in Step 2.		
	Head unit will not read flash memory.	The file folder name was changed or put into a different folder.	Make sure only the file that is shown in step 2 is copied over.		
		The USB port was installed incorrectly.	Make sure the port is working correctly by plugging in an iPod or flash memory with a few MP3's on it and seeing if it will play the music. If that's not working then there's no way for the update to work. Try plugging the flash drive directly into the tuner without the extension cable.		